
Meridian 1

Fiber Remote IPE

Description, installation, and maintenance

Document Number: 553-3001-020

Document Release: Standard 4.00

Date: August 1996

© 1994, 1996

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

December 1994

Standard, release 1.0.

December 1994

Standard, release 2.0. Reissued to included technical content.

July 1995

Standard, release 3.00. Reissued to add fibre-optic link engineering and SDI connection information. Changes are noted by revision bars in the margins.

August 1996

Standard, release 4.00. Reissued to remove the DANGER sign because the laser was replaced with an LED. Also *span* is replaced by *link*. Changes are noted by revision bars in the margins.

Contents

About this document	1
References	2
Fibre Remote IPE product description	3
System overview	3
System description	4
Fibre Remote IPE physical architecture	4
Fibre Remote IPE functional architecture	10
Functional description	13
Fibre Superloop Network card	15
Fibre Peripheral Controller card	19
Engineering guidelines	24
Fibre Remote IPE capacity	24
Engineering the fibre-optic link	26
System planning and ordering	32
System selection	32
Fibre Remote IPE site planning	33
Equipment installation and configuration	39
System overview	39
Preinstallation preparation	41
Preparing the site	41
Unpacking and inspection	42
Taking inventory	43
Installing the fibre-optic link	43
Selecting the Fibre Superloop Network card slot	46

Meridian 1 fibre-optic equipment installation	47
Installing and verifying Meridian 1 operation	47
Installing the Fibre Superloop Network card	48
Installing fibre-optic patchcords	50
Installing system monitor and TTY cables	52
Connecting the fibre-optic link to Meridian 1	57
Floor-standing column Fibre Remote IPE installation	58
Installing the floor-standing column	58
Installing cards in the Remote IPE Module	58
Installing fibre-optic patchcords	60
Installing system monitor and TTY cables	62
Connecting the fibre-optic link to the Remote IPE Module	64
Wall-mounted Fibre Remote IPE installation	65
Installing the wall-mounted cabinet	65
Installing cards in the wall-mounted cabinet	68
Connecting fibre-optic link to the wall-mounted cabinet	69
Connecting TTY and subscriber loop cables	73
Connecting attendant console power cord to the wall-mounted Fibre Remote IPE	75
Connecting PFTU to the wall-mounted Fibre Remote IPE	75
Configuring the Fibre Remote IPE	77
Configuring fibre-optic cards	77
Configuring the system monitor address	78
Defining the loadware	79
Configuring the MMI port	80
Fibre Remote IPE acceptance testing	83
Overview	83
Checking the system	84
Setting up test conditions	85
Performing acceptance testing	85
Voice calls	86
Checking the MMI terminal operation	88
Checking link protection switching	88
Removing the test setup	90
Generating traffic reports	90

Fibre Remote IPE maintenance	91
System overview	91
Diagnostic tools	92
Hardware diagnostic tools	92
Software diagnostic tools	96
Using maintenance programs	103
Logging in on the maintenance terminal	103
Accessing the program	104
Responding to error messages	104
Exiting the program	104
Logging out	104
Logging in and using a maintenance telephone	105
Isolating and correcting faults	107
Types of faults	107
Fault isolation steps	107
Meridian 1 fault isolation and correction	109
Fibre Remote IPE fault isolation and correction	111
Fibre Superloop Network card fault isolation and correction	113
Fibre Peripheral Controller card fault isolation and correction	120
Fault isolation and correction using MMI maintenance commands	124
Replacing Fibre Remote IPE cards	128
Unpacking replacement cards	128
Removing and replacing a card	128
Reinstalling covers	132
Packing and shipping defective cards	132
 System messages and MMI commands description	
133	